

“STEP UP” POWER STEP MANUAL OVERRIDE FEATURE

The manual override feature should ONLY be used in the event of power loss.

To operate the upper motor without power, simply pull the pin out of the upper motor that connects it to the step frame and pull the step out until it locks into the set-up position. To lower the bottom steps you must pull the brake release lever located at the end of the lower motor then you can rotate the bottom steps into set-up position. It is **IMPORTANT** to reset the brake lever into the locked position before traveling.

If the motor brake is not locked into position the lower section could drift down during travel and damage the unit.

The images below show the lower motor and how to operate it manually.

